


POWER X-CHANGE

PUREPOWER
BRUSHLESS

ULTRASONIC SENSORS

The sensors detect obstacles and physical boundaries such as hedges, walls or trees



INTEGRATED CAMERA

Using the integrated camera, the FREELEXO CAM 500 recognises the boundaries of the lawn to be mowed by detecting lawns based on colours and structures. Visual boundaries can be bark mulch, tar and stones.

CHECKLIST: IS MY GARDEN SUITABLE?



Lawn area of uniformly green colour



Irregularities in colour (e.g. leaves, scorched areas)




Clearly defined and recognisable lawn edges*



No clearly recognisable lawn edges



Simple design, uniform shape




Many separate areas, bottlenecks and recesses

* The lawn area needs to be checked for suitable lawn boundaries.

© 2023 Einhell Germany AG - Subject to change without notice. E80E - Art. No. 110672 / 01 - As of 03.2023

Einhell


TRUE CORDLESS FREEDOM WITH THE FREELEXO CAM



Einhell

POWER X-CHANGE

TRUE CORDLESS FREEDOM WITH THE FREELEXO CAM



Einhell Germany AG

Wiesenweg 22
94405 Landau/Isar
Germany

info@einhell.de
www.einhell.de

Service:

Einhell Service
Eschenstr. 6
94405 Landau/Isar
Germany

Service-DE@einhell.com
www.einhell-service.com

The **FREELEXO CAM 500** automatically recognises the boundaries of the lawn to be mowed. **This saves the time-consuming and tedious installation of a perimeter wire** and the robotic lawn mower can start immediately.

einhell.de
>>>

ASSEMBLY AND INSTALLATION IN THE SHORTEST POSSIBLE TIME

1 INSTALL CHARGING STATION AND GUIDE WIRE *



* This is not a boundary wire, but simply a 5 m² loop around the charging station that the robotic lawn mower uses for docking.

2 CALIBRATION AND INITIALISATION



Place FREELEXO in the charging station, calibrate and start initialisation run.

3 START



EASY AND STRAIGHTFORWARD INSTALLATION

The FREELEXO CAM is up and running in next to no time.



The painstaking and time-consuming installation of a perimeter wire throughout the garden is now completely unnecessary thanks to the camera system of the FREELEXO CAM!

THE FREELEXO CAM IN DETAIL

POWER X-CHANGE

The FREELEXO CAM is a member of the Power X-Change family. The battery can be used in all Einhell cordless devices and is replaceable at any time.



SEPARATE GARDEN AREAS

The robot mower can be put to flexible use thanks to its mowing mode for secondary areas. Simply place the robot mower in any secondary area, insert the battery and off it goes.

VIRTUAL FENCE MAKES IT POSSIBLE – THANKS TO MAGNETIC BAND ACCESSORIES

Laid out in the garden, the enclosed magnetic band acts as a virtual fence. The built-in magnetic sensors in the FREELEXO CAM detect the magnetic tape and turn off at its border. In this way, areas can be excluded that should not be approached.




SHORT-TERM DEMARICATION

A garden party is coming up and the seating area should temporarily not be approached by the robot lawn mower.




NEW TREE PLANTED

The freshly planted tree is still fragile and will be protected from collisions with the robotic lawnmower by the virtual fence for the first while.



FLOWER MEADOW IN THE GARDEN

The flower meadow in the garden is just starting to grow and already attracts insects, but should not be crossed by the robotic mower.



LAWN EDGES MADE BETTER

Lawn edges that are poorly defined or hard to recognise by the robot lawn mower can be upgraded by the magnetic tape for optimum demarcation of the mowing area in the garden.

FREELEXO CAM



FREELEXO CAM 500

PXC battery voltage / capacity	18 V / 3.0 Ah
For lawn areas of up to approx.	500 m²
Cutting width	18 cm
Cutting height adjustment	infinitely / 20 - 60 mm / central
Magnetic band for virtual border	5 m, included in delivery
Suitable for slopes up to	25%
Art. No.	34.139.91

* The stated area coverage is based on the assumption of ideal conditions



TRUE CORDLESS FREEDOM

No perimeter wire required



THEFT PROTECTION

The lawn robot is protected against theft by a pin code and the warning signal



SLOPES UP TO 25%

The robot lawn mower is suitable for slopes up to 25%



RAIN SENSOR

for lawn-friendly operation



INTUITIVE KEYPAD

Easy to operate thanks to the mowing time programmer for lawn care every day or every two days.

PRODUCT VIDEO

Want to learn more details about the mower and find out if the FREELEXO CAM is suitable for your garden? Then take a look at our video.



FREELEXO CAM ACCESSORIES

	Article No.	Items supplied
 Magnetic Band Set	34.140.28	Magnetic band (length: 20 m), 20 fastening hooks

